Installation of Rechargeable Battery Pack into the SC110 Mk3

- 1. Open the lid of the unit by pushing a flat bladed screwdriver into the slot on either side of the box in turn to release a catch.
- 2. Clip the battery pack onto the PP3 lead coming of the main board.
- 3. Remove the yellow tape backing from the battery pack
- 4. Secure the battery pack onto the bottom of the box were there is space making sure it is secure.
- 5. Check that the clock is running with the pack connected.
- 6. Place the lid back onto the box making sure that you can hear two clicks as the slots are lined up correctly.
- 7. If the clock fails to respond to any button then a reset may be needed which means taking out the battery pack, possibly giving the cells a proper charge, then replacing the pack.

AWR Technology

15th August 2007