

IH DEFAULT MENU

V1.743

POWER UP

SETUP OPTION

'OFF' or 'UNPARK' if 'TRACK AT START = Y'

DEFAULT

(M)

OBJECT

- GUIDE
- CENTRE
- MOVE
- SLEW

SPEED at which telescope moves
when TELESCOPE MOVE button pressed

ACTIONS
AT ANY TIME

- UP
- DOWN
- LEFT
- RIGHT

- U1
- U2
- U3

- Ev

- C-CANCEL
- M-MENU
- E-ENTER

TELESCOPE MOVE buttons within the circle

- DEC towards your POLE
- DEC away from your POLE
- RA Plus (towards the EAST)
- RA Minus (towards the WEST)

USER buttons

These operate the RELAYS in the ADV Drivebox

EVENT button Stores up to 32 events

The FUNCTION BUTTONS take the action of the word above it.

No keys pressed it is TRACKING

Tracking STOPS if it reaches a limit in the set envelope.

The function '..' means MORE OPTIONS

DATA ENTRY with a BLOCK cursor needs number pad entry.

SCROLLING data entry by FUNCTION BUTTON up and down arrows.